



Mechanism Instructions - E51

Seating Inc.

P.O. Box 898 ♦ 60 State Street ♦ Nunda, NY 14517 ♦ Tel: 800•468•2475 ♦ seatinginc.com

Tilt Resistance - (There is a hand wheel under the front of the mechanism that can't be seen in this picture) Turn the Hand Wheel counter clockwise to increase the tension for heavier people, clockwise to decrease the tension for lighter people.

Seat Tilt

This paddle adjusts seat & backrest angle as a unit and allows chair to rock. Lift paddle to allow chair to "rock". Push paddle down to lock the chair in any desired position.



Pneumatic Lift Adjustment

Lift the tab up to adjust seat height

E51 Heavy Duty Tilter