

Mechanism Instructions - Q25 ASD

Seating Inc.

P.O. Box 898 ♦ 60 State Street ♦ Nunda, NY 14517 ♦ Tel: 800•468•2475 ♦ seatinginc.com

Adjustable Seat Depth


Lift tab up to allow for adjustment of seat forward & back.
To lock seat in desired position, push the tab back down.

Pneumatic Lift Adjustment

Lift tab up to adjust seat height.

Tilt Lock Adjustment


Turn Forward (Clockwise)
to release lock and tilt freely.
Turn Rearward (Counter clockwise)
to Lock Tilt Position.



Tension Adjustment

Pull the handle out away from
the seat. Then turn the handle
forward to tighten, or rearward
to loosen.

Q25 2:1 Synchro Tilter with Adjustable Seat Depth



Quick Set Back Height Adjustment

Step 1

Release Back Height

While sitting in the chair put both hands behind you under the back cushion of the chair. Pull the back cushion up to it's highest possible position - then let go and allow it to drop all the way down. Push gently down on the cushion to make sure it is has returned all the way to the bottom.

Step 2

Back Height Adjustment

While sitting in the chair put both hands behind you under the back cushion of the chair and pull up slowly until you hear the mechanism click. Let go and test the back height. Repeat the procedure until it has reached the desired height.