


Q22 ASD - Posture Plus

Mechanism Instructions



- 1 Pneumatic Lift Adjustment: Lift lever towards seat to activate height adjustment.
- 2 Back Rest Angle Adjusment:
 Pull up on lever to make adjustment to back rest angle.
 To lock the back rest in place, press the lever down.
- 3 Adjustable Seat Depth (OPTIONAL):
 Lift lever up to allow for adjustment of seat forward & back. Release lever to lock seat in desired position.

All adjustments are made while seated.





