



# Q35 - HD Superior Synchro

## Mechanism Instructions



### ① **Tilt Lock Adjustment:**

Turn Forward (Clockwise) to release lock and tilt freely.  
Turn Rearward (Counter Clockwise) to lock tilt position.

### ② **Pneumatic Lift Adjustment:**

Lift tab up to adjust seat height.

### ③ **Tension Adjustment:**

Pull the handle out away from the seat, then turn the handle forward to tighten, or rearward to loosen.

All adjustments are made while seated.